

FM3 - Countdown Timer with Clock - Operating Instructions

Timer Mode (HH, MM, SS)

1. Press **Reset Timer** to select timer mode
2. Turn **Knob** to set desired time
3. Press the **Start/Stop** button to start or stop the timer


Clock Mode

Setting the time:

1. Press and hold the **Clock** button to enter the set time mode
2. Turn the **Knob** to set the hours
3. Press the **Clock** button again to switch to minutes
4. Turn the **Knob** to set the minutes
5. Press the **Clock** button again to return to normal display

Red-yellow-green Display LED's

- The **Green** light comes on when the timer is started and begins to blink at the **Green** warning time
- When the **Yellow** warning time is reached, the **Green** light goes off and the **Yellow** light comes on as a warning to finish shortly or "wrap it up"
- When the timer reaches zero, the **Red** light comes on and the **Yellow** light goes off. The timer stops when the **Red** light appears
- Press the reset button to turn off the **Red** light and reset the timer
- The timer will automatically shut down after a few minutes if not being used



The information contained in this drawing is the sole property of Audio Visual Furniture International. Any reproduction in part or as a whole without the written permission of Audio Visual Furniture International is prohibited. We can build or modify stock configurations to suit customer specifications. Please contact us to discuss how this service can help meet your needs. Some quantity restrictions may apply. Specification subject to change without notice. Computers, cameras, monitors, etc. are shown to illustrate product usage and are not included unless otherwise noted.